O2 SENSOR FITTINGS



#63 O2 MOUNTING BOSS M18 X 1.5 SS/#63S, USE #107 PLUG



#63-50 RECESSED BOSS M18 X 1.5, SS/#63-50S, USE #107 PLUG



#69 O2 MOUNTING BOSS FOREIGN CAR/ MOTORCYCLE M12 X 1.25, USE #107-69 PLUG



#63-2H 304SS HEAT TEMP BOSS SENSOR BUNG M14 X 1.50, STEP DOWN ***NEW***



#63-66 02 SENSOR BOSS M .66" x .87' FITTING ***NEW***



#69-50S STAINLESS STEEL BOSS (STEPPED) FOREIGN CAR/MOTORCYCLE M12 X 1.25 USE #107-69S PLUG



#63-14 02 BOSS, SS/#63-14S M14 X 1.25, STEPPED, USE #107-14 PLUG



#63-69 DUAL-THREADED SS/#63-69S, ZINC/#63-69Z M18X1.5 OUTER TO M12X1.25 INNER USE #107-69 PLUG (AVAILABLE IN ZINC)



#69-1415 O2 BOSS, SS/#69-1415S FOREIGN CAR/MOTORCYCLE M14 X 1.5, USE #107-1415 PLUG



#63-18NPT STEEL PIPE THREAD MOUNTING BOSS M18 X 18 NPT



#63-80 STEEL MOUNTING BOSS FOR TURBO AND HIGH PERFORMANCE M18 X 1.5 (.80" LONG) USE #107 PLUG

ENDING IN 'S' = STAINLESS STEEL ENDING IN 'Z' = ZINC COATED



#63-21 STEEL MOUNTING BOSS M18 X 25.41 X 15.9M ***NEW***



#63-95 STEEL MOUNTING BOSS M18 X 1.5, STEPPED 12 mm SHOULDER FITTING USE #107 PLUG

OXYGEN SENSOR SOCKETS



#63-30 STEEL MOUNTING BOSS ANGLE CUT AT 30 DEGREES, SS/#63-30S (PREVIOUSLY #63-45), ZINC/#63-30Z M18 X 1.5 USE #107 PLUG



#63-100 o2 BOSS, SS/#63-100S TURBO AND HIGH PERFORMANCE M18 X 1.5 (1.00" LONG) USE #107 PLUG



#63-34 STEEL MOUNTING BOSS 1" OD, 3/8" NPT, 1/2" W ***NEW***



#63-125 STEEL MOUNTING BOSS 1 1/8" X 1/2" FITTING, STEPPED ***NEW***

#889-1 OFFSET OXYGEN SENSOR SOCKET

3/8" DRIVE X 7/8" MADE FROM CHROME MOLYBDENUM PREVENTS DAMAGE TO WIRES



#63-45SM12 STAINLESS STEEL MOUNTING BOSS ANGLE CUT AT 30 DEG. M18 X 1.25, USE #107-69S PLUG ***NEW***



#63-2015 STEEL MOUNTING BOSS M20 X 1.5, FOR DIESEL APPS. ***NEW***



#63-5140-2 MTG. BOSS STEPPED WITH WIDE EDGE (.13" THICK) M18 X 1.5 THREAD USE #107 PLUG



STEEL MOUNTING BOSS (STEPPED) ANGLE CUT AT 30 DEGREES M18 X 1.5. USE #107 PLUG

#63-45STEP



#63-5916



OXYGEN SENSOR SOCKET 3/8" DRIVE

COMMON 6 POINT, 7/8" (22mm)

SIDE CUTOUT PREVENTS DAMAGE

 $\pmb{\#63\text{-}46} \text{ steel mounting boss}$ M18 X 7/8 (NON-METRIC) USE #107-46 PLUG



STEEL MOUNTING BOSS SS/#63-5916S STEPPED DESIGN WITH THICK EDGE (.08" THICK) M18 X 9/16 FINE THREAD



#63-49R STEEL MOUNTING BOSS 49 DEGREE ANGLE WITH COPED DESIGN M18 X 1.5-USE #107 PLUG. SS/#63-49RS



#63S-M16 STAINLESS STEEL MOUNTING BOSS M16 X 1.5 THREAD

POLLUTION CONTROL INDUSTRIES

Proud Manufacturer to the Auto Industry for Over 30 Yearsl

O2 SENSOR PLUGS



#107 O2 SENSOR PLUG, M18 X 1.5 SS/#107S, ZINC/#107Z



#107-14 O2 SENSOR PLUG, M14 X 1.25 SS/#107-14S, ZINC/#107-14Z



#107-2215 O2 SENSOR PLUG, M22 x 1.5 SS/#107-2215S, ZINC #107-2215Z ***NEW***



#107-46 O2 SENSOR PLUG, M18 X 7/8"



#107-69 O2 SENSOR PLUG, M12 X 1.25 SS/#107-69S, ZINC #107-69Z



#107-69Z ZINC COATED 02 SENSOR PLUG **ALL M12 X 1.25 FITTINGS**



#107-1415 O2 SENSOR PLUG, M14 X 1.5 SS/#107-1415S, ZINC #107-1415Z



#107-1615 O2 SENSOR PLUG, M16 X 1.5 SS/#107-1615S, ZINC/#107-1615Z



#107H115 (HEX TOP) O2 SENSOR HEX PLUG, M18 X 1.5 SS/#107H115S, ZINC/#107H115Z



#107Z ZINC COATED 02 SENSOR PLUG **ALL M18 X 1.5 FITTINGS**

ENDING IN 'S' = STAINLESS STEEL ENDING IN 'Z' = ZINC COATED

O2 SENSOR FLANGES



#811 02 SENSOR FLANGE **OUR MOST POPULAR FLANGE** TOYOTA, CHRYSLER, & OTHER IMPORTS M18 X 1.5 THREAD USE WITH #811-1 GASKET

#813 STEEL 02 SENSOR FLANGE POPULAR TOYOTA AND FOREIGN CAR STEEL FLANGE WITH WELDED BOLTS NO CENTER THREAD, USE #813-1 GASKET

#813TS STEEL 02 SENSOR FLANGE POPULAR TOYOTA AND FOREIGN CAR FLUSH BOLTS, CENTER THREAD M18X1.5 USE #813-1 GASKET *** NEW***

O2 SENSOR GASKETS



#811-1

02 SENSOR GASKET FOR #811 FLANGE

#813-1

02 SENSOR GASKET FOR #813/813TS FLANGE

#811-2

02 SENSOR COPPER GASKET 0.870 OD X 0.730 ID X 0.040 THICK USE W/ #107 PLUG & ALL M18 X 1.5 FITTINGS

FOR A CUSTOM DESIGN NOT SHOWN HERE PLEASE CALL OR EMAIL US AT:

1-800-447-8760 | sales@pciinc.com



POLLUTION CONTROL INDUSTRIES

Proud Manufacturer to the Auto Industry for Over 30 Years!